

Protect against moisture and steam with good ventilation. The most common problem associated with improper maintenance is water damage. Lacquer makes the wood surface water resistant but NOT WATERPROOF. Clean up spills immediately. Use a blotting rather than a wiping action. Water left over a period of time will cause white spots in the finish and result in lacquer failure. Counter tops that do not have raised edges to keep water off the cabinets, will need more maintenance.

For white thermo-foil cabinets, use a clean, damp cloth. If using a mild all-purpose cleaner for more stubborn stains, read the manufacturer's directions and test on a non-conspicuous area before cleaning.

With a little bit of care, your vanity will last for many years!