

**ACCESSORY ITEMS** like fill strips, toe kick plates and trim strips help put the finishing touches on new or remodeled bathroom projects. Other items like medicine cabinet hinges, knobs, and soft-close door cushions are available as needed to keep your bathroom cabinetry functioning properly. See the following page for pricing/ordering information. See SPEC-4 for dimensions and INFO-2 for installation suggestions.

**FILL STRIPS (FS)** are normally used to “fill-in” gaps between a cabinet and wall. Fill strips come in 2 parts (face frame and toe kick sections) to match the vertical and horizontal wood grain.

**TRIM STRIPS (TS)** are typically scribed and cut on the job site to finish and fill small gaps normally created if walls are not square or plumb.

**TOE KICK PLATES (TKP)** are designed to cover seams from adjoining cabinetry. They get cut to size at the job site for a custom “built-in” fit.

**BASE BOARDS (BB)** are optional and in conjunction with TKPs (either placed in front of or below TKP) can be used to cover 2 x 4 wood platforms built to place vanities even higher off the floor.



Toe Kick Plate



Base Board



Fill Strip (face frame section)



Fill Strip (toe kick section)



Med. Cabinet Hinges (MCH)



Med Cab. Touch Latch (MCTL)



Soft-Close Door Stops (SCDS)



Med. Cabinet Pulls (MCP)