

**\*\*\* NOTE \*\*\*** Drawer boxes are fitted for each opening, numbering them underneath with a pencil will make re-installation go easier.

**STEP 1:**

With both hands, gently squeeze each release clip lever (mounted under drawer box) as indicated by arrows

**STEP 2:**

While release clip levers are squeezed, simultaneously slide (pull) drawer out in the direction of the arrow, away from the cabinet as though you were opening the drawer completely.

***DO NOT force the drawer box up, down or side to side*** until the drawer box has been released from the drawers slides. This may break the drawer slide mounting bracket or pull the screws out of the drawer front.

To re-install, simply pull drawer slides out all the way, place drawer box on the slides, and push drawer all the way in until you hear an audible "click".

